

J BEADS



72-1010 10mm J Bead (3000mm)
72-1110 13mm J Bead (3000mm)

MUD ON J BEADS



72-1710 13mm Mud On J Bead (3000mm)

PRODUCT DESCRIPTION & APPLICATION

- 72-1010 10mm 3m Casing Bead & 72-1110 13mm 3m Casing Bead were designed to encase the end of plasterboard where they abut other substrates
- This product is easily painted and will never rust leaving a clean finish
- 72-1710 13mm 3m Mud On Set Bead is designed for butting plasterboard to other substrates such as Masonry, Glass, Window and Door encasement's
- Do not use Trim-Tex Regular, Shadow or Super J Beads in this application

INSTALLATION:

- Ensure the substrate is true and plumb
- 72-1010 10mm 3m J Bead and 72-1110 13mm 3m j Bead are a dry fit product. Prior to fixing off the plasterboard ensure the J Bead is in the correct position as the lining fasteners will hold this product to place
- 72-1710 13mm 3m Mud On Set J Bead is to be installed by using Trim-Tex 72-847 Spray Adhesive and 10mm staples at 200mm centers
- Set this Trim-Tex Bead with approved compounds (refer to ASTM-C475 or the Plasterboard Manufacturers Specifications)

NOTES:

1. The incorrect installation of Trim-Tex Beads will void any Warranty (see Trim-Tex Product Warranty at www.wallboardtools.com.au)
2. Refer to UV Stabilized Trim-Tex beads or RenderEdge beads for external use
3. On vertical installation of Trim-Tex beads allow 6mm minimum clearance above floor for structural movement

Spray Adhesive 847

Spray a liberal coat of 847 to the inside of the bead as well as the surface of the plasterboard. Apply firm even pressure to ensure a solid bond.



Trim-Tex 847 Spray Adhesive is a high tack, pressure sensitive spray adhesive specifically designed to be used to install Trim-Tex Beads.

PRODUCT DATA SHEET

